



RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Specification

12 1/2"



Dimensions and battery

Ø Total	28.60 mm
Ø Case fitting	28.00 mm
Movement height	4.40 mm
Movement rest	0.60 mm
Height of stem	1.90 mm
Stem: Thread / Distance	0.90 mm / 0.90 mm
Battery / Autonomy	Nr. 395 / 48 Months

Performances


Torque T	Minute hand: 6 µNm
Operating temperature	0°C - 50°C
Res. against magn. fields	18.8 Oe = 1500 A/m
Resistance against shock	NIHS 91 - 10

Functions


Position I (crown)	Neutral
Position II (crown)	Setting the date (quick mode)
Position III (crown)	Setting Time




RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch



A



B



C

Technical Instructions 4002.B

Assembling

1. 2000.577.G Main plate
2. 3305.314.CO Cannon pinion with driver (Aig 2)


Moebius 8200 grease must be placed between the steel tube and the brass wheel. The steel tube must be placed into the center hole of the main plate.
3. 2030.019.CO Centre bridge


Use one screw 4000.250 to fix the center bridge.
4. 3001.041 Sliding pinion


The sliding pinion must be held using a tweezers, until the stem is inserted.
5. 3000.177.CO Handsetting stem


Prior to the insertion of the stem, some greace must be placed on the square part of the stem.
6. 3017.049 Setting lever


The cam on the setting lever must be inserted into the cut out on the stem. (the setting lever must be greaced)
7. 3905.049 Setting lever jumper (3 positions)


The setting lever jumper (3 positions) must be tensioned and inserted into the setting lever. Use one screw 4000.250 to fix the setting lever.
8. 4000.250 Screw
9. 3015.076 Yoke (3 positions)


The yoke must be inserted below, into the cut out of the sliding pinion.
10. 3905.058 Yoke spring


The yoke spring must be positioned on the yoke. The opposite end of the yoke must be positioned around the pillar of setting lever. Use Moebius 8200 to grease the yoke.
11. 3622.039 Stator
12. 3603.065 Plastic bracket


Use 4 screws 4000.250
13. 4000.250 Screw
14. 3715.094.RK Rotor centre



Use an antimagnetic tweezers to place the rotor.
15. 3147.047.CO Intermediate wheel (chrono)

16. 3136.170.CO Second wheel (height 0)


RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Technical Instructions 4002.B

Assembling



D

17. 3136.148.CO Second wheel (short)



18. 3122.056.CO Third wheel




19. 2020.164.G Train wheel bridge



Attention: Prior to the fastening process of the bridge, all pins of the wheels must be visible in the holes in the bridge. Use 3 screws 4000.250.

20. 4000.250 Screw



E

21. 9014.000 Moebius 9014



Use Moebius 9014 on bearing of all rubis

22. 3621.054.RK Coil (movement)



The wire of the coil (red area) is very sensitiv to mechanical impacts.
 Hold the coil only outside the red area. Fix the coil by 1 screw 4000.250.


23. 4000.250 Screw



24. 3503.059 Tube



25. 3603.034 Battery insulator




F

RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Technical Instructions 4002.B

Assembling



G

26. 4000.248 Screw



27. 3503.068 Tube




28. 3603.076 Circuit insulator



29. 3601.107 Pusher contact spring



Make shure, that the pusher contact spring is placed correctly onto the pillars.



H

30. 3600.010 Battery



Battery

Use a plastic tweezers to place the battery (to avoid short circuit of battery).



31. 3601.109 Bridle +



Bridle +

Insert the two brackets of the battery bridle under the electronic module cover and fasten the battery bridle by 1 screw 4000.250.

32. 4000.250 Screw




I


RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Technical Instructions 4002.B

Assembling



J



K

33. 2000.577.G Main plate



34. 9014.000 Moebius 9014

Use Moebius 9014 on bearing of all rubis



35. 3004.164 Setting wheel

Use Jismaa 124 or Greace Moebius on both setting wheels.



36. 3007.054.CO Minute wheel

Use Moebius 9020



37. 2130.143 Minute train bridge

Use 2 screws 4000.305



38. 4000.305 Screw



39. 3004.181 Tens indicator driving wheel

The short tooth of the tens indicator driving wheel must point to the center of the movement.



40. 3500.059 Tens jumper

Moebius 8200 greace must be placed between the tens jumper and the tens indicator driving wheel.



41. 2130.142 Tens jumper maintaining plate

Make shure, that the tens indicator driving wheel is not blocked prior to the fastening process. Use 2 screws 4010.306. Place the spring loaded bracket outside of the tens jumper.



42. 4010.306 Screw



43. 3301.285 Hour wheel (Aig. 0)

Use Moebius 9020



44. 3315.016 Hour wheel friction spring

Must be placed onto the hour wheel



45. 3004.176.CO Date indicator driving wheel

Moebius 9020 must be used in the center of this wheel



46. 3500.049 Date jumper



Moebius 8200 greace must be placed between the date jumper and the date jumper spring



RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch







Technical Instructions 4002.B

Assembling



- | | |
|--|--|
| 47.  3504.214.AD | Units indicator
Teeth must be greased using Moebius 8200. The "half moon" cut out on the unit indicator must point to the stem (position 3h). |
| 48.  3147.054 | Tens intermediate wheel |
| 49.  2130.141 | Date indicator maintaining plate
use 1 screw 4000.250 |
| 50.  3905.050 | Date jumper spring
Insert the spring into the opening of the date indicator maintaining plate |
|
 | |
| 51.  3504.215.AD | Tens indicator (T3/G12)
The "half moon" cut out on the tens indicator must point to the stem (position 3h). |
| 52.  2130.140 | Date mechanism maintaining plate
Assure that the tens intermediate wheel is not blocked, prior to the fastening process. Use 2 screws 4000.250 to fix the date indicator maintaining plate |
| 53.  3506.072 | Dial support |
| 54.  4000.250 | Screw |
|
 | |
| 55.  9010.000 | Moebius 8200
Micogliss D5 can be used |
| 56.  9018.000 | Jismaa 124
Grease Moebius or Micogliss D5 an be used |
| 57.  9020.000 | Moebius 9020 |


RONDA AG
 Hauptstrasse 10
 CH-4415 Lausen/Switzerland
 Phone ++41 (0)61 926 50 00
 Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Voltage of battery

Electrical checking
Consumption (M2) of movem. (Pos. I)

Consumption (M2) of movem. (Pos. III)

Lowest voltage for movement (M2)

Accuracy (seconds / month)

Resistance of the coil (M2)


RONDA AG
Hauptstrasse 10
CH-4415 Lausen/Switzerland
Phone ++41 (0)61 926 50 00
Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Electrical checking

Coil insulation (M2)



RONDA AG
Hauptstrasse 10
CH-4415 Lausen/Switzerland
Phone ++41 (0)61 926 50 00
Fax ++41 (0)61 926 50 50
www.ronda.ch • info@ronda.ch

Test of the motors

Accelerated test of movement (M1)

