

ROXER

POSTE Z

Seiler



Vacuum workstation:

User instructions



Essential

Retain this document for later reference.

1 Technical data

Maximum suction rate	Current	Motor power	Voltage	Frequency	Protection rating	Noise level
m ³ /hr	A	W	V	Hz	IP	db (A)
4.1	1.11	180	230	50	54	48
4.7	1.07	210		60		
4.7	1.07	210	115	60	54	48

2 Operation

Unit without pedal

Stop/start switch at "O" = Pump stopped

Stop/start switch at "I" = Pump activated



Unit with pedal(s): Plug the pedal(s) into the intended sockets (fig. 1). Check that the red switch on the unit is in the "I" position (fig. 2).

One-pedal unit

Stop/start switch at "I" = Pump stopped.

Optional pedals

Stop/start switch at "I" + pedal depressed = Pump activated.



Two-pedal unit

Stop/start switch at "I" = Pump stopped.

Stop/start switch at "I" + 1 or 2 pedals depressed = Pump activated.



(fig.2)



(fig.1)

3 Maintenance

Check the air intake filter (fig. 3).

Clean the cartridge and felt filter.

Replace it if necessary (intake filter P2.8 n°1100020001).

Pump dries without maintenance.

Filter cartridge →



(fig.3)