

Step 1

Locate the conical end pin that is covering the whole



Step 2

With the help of the key, unscrew this conical part



Step 3

Then, screw the 23.501-A

