



Step 1.

Remove the front cover.

Step 2.

Pull out the metal pipe.

Step 3

Reverse the round rubber mat