




## For Slanted Push Button

10<sup>1</sup>/<sub>2</sub>mm



## For Parallel Push Button




NEW

Dual Time

**FS16**

height 5.10mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 12H  
 2 years battery life (SR626SW)




NEW

Dual Time

**FS26**

height 5.10mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 3H  
 2 years battery life (SR626SW)




NEW

Dual Time

**FS17**

height 5.25mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 12H  
 2 years battery life (SR626SW)




NEW

Dual Time

**FS27**


height 5.25mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 3H  
 2 years battery life (SR626SW)



Day/Date

**FS60**


height 5.10mm  
 chrono min at 10H/sec at 6H/  
 retrograde day at 3H  
 2 years battery life (SR626SW)



Day/Date

**FS61**

height 5.25mm  
 chrono min at 10H/sec at 6H/  
 retrograde day at 3H  
 2 years battery life (SR626SW)




High Hand Available

Date

**FS00**

height 4.13mm  
 chrono min at 10H/sec at 6H/  
 24 hour at 2H  
 2 years battery life (SR626SW)



High Hand Available

Date

**FS01**

height 4.28mm  
 chrono min at 10H/sec at 6H/  
 24 hour at 2H  
 2 years battery life (SR626SW)



High Hand Available

Date

**FS10**

height 5.10mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 12H  
 2 years battery life (SR626SW)




High Hand Available

Date

**FS20**

height 5.10mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 3H  
 2 years battery life (SR626SW)




High Hand Available

Date

**FS11**

height 5.25mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 12H  
 2 years battery life (SR626SW)



High Hand Available

Date

**FS21**

height 5.25mm  
 chrono min at 9H/sec at 6H/  
 24 hour at 3H  
 2 years battery life (SR626SW)

- Center second hand Chronograph
- Quick Reset (by Heart Cam reset system)
- Click feeling Push Button handling (by Heart Cam reset system)

※ FS16, FS26 → Case Compatible (height 5.10mm)  
 ※ FS17, FS27 → Case Compatible (height 5.25mm)  
 ※ FS10, FS20, FS60 → Case Compatible (height 5.10mm)  
 ※ FS11, FS21, FS61 → Case Compatible (height 5.25mm)


# CHRONOGRAPH

## OS SERIES

13½"

High Hand Available


High Hand Available



Date

### OS10


height 4.13mm  
 chrono hour/min/sec  
 3 years battery life (SR927W)



Date

### OS20

height 5.10mm  
 chrono min/sec, 24 hour  
 3 years battery life (SR927W)



### OS30


height 4.13mm  
 chrono hour/min/sec  
 3 years battery life (SR927W)



Date

### OS11

height 4.13mm  
 chrono min/sec  
 3 years battery life (SR927W)




Date

### OS21

height 5.10mm  
 chrono min/sec, 24 hour  
 3 years battery life (SR927W)

## OS PROFESSIONAL SERIES


13½"



Date  
 Chrono  
 (1/20 Second)

### OS60

height 4.13mm  
 chrono hour/min/sec + 1/20 second  
 FAST TURNING CHRONO HAND:  
 1/20 sec. measuring indicated by  
 6H second hand  
 (operative in specific mode)  
 2 years battery life (SR927W)



Date  
 Chrono  
 (1/20 Second)

### OS25

height 5.10mm  
 chrono min/sec + 1/20 second, 24 hour  
 FAST TURNING CHRONO HAND:  
 1/20 sec. measuring indicated by  
 6H second hand  
 (operative in specific mode)  
 2 years battery life (SR927W)



Date  
 Alarm  
 Chrono  
 (1/20 Second)

### OS80


height 4.68mm  
 chrono hour/min/sec + 1/20 second & alarm  
 FAST TURNING CHRONO HAND:  
 1/20 sec. measuring indicated by  
 6H second hand  
 (operative in specific mode)  
 2 years battery life (SR927W)



Date  
 Chrono  
 (1/100 Second)

### OS90


height 4.13mm  
 chrono min/sec + 1/100 second, 24 hour  
 FAST TURNING CHRONO HAND:  
 1/20 sec. measuring indicated by  
 center hand  
 (operative in specific mode)  
 2 years battery life (SR927W)



Date  
 Retrograde Chrono  
 (1/20 Second)

### OS62


height 4.13mm  
 chrono hour/min/sec + 1/20 second  
 FAST TURNING CHRONO HAND:  
 1/20 sec. measuring indicated by  
 6H second hand  
 (operative in specific mode)  
 2 years battery life (SR927W)



Date  
 Retrograde Chrono  
 (1/20 Second)



### OS22

height 5.10mm  
 chrono min/sec, 24 hour  
 FAST TURNING CHRONO HAND:  
 1/20 sec. measuring indicated by  
 6H second hand  
 (operative in specific mode)  
 2 years battery life (SR927W)




# HIGH HAND SERIES


## BASIC



2026




2035




2036




2039



2033



203A



2115



2117

## SLIM



1L22





1L26



1L32





1L36



5R21



5R22



5Y20



5Y26




5Y30



5Y36


## 6P SERIES




6P23/6P73



6P25/6P75



6P27/6P77



6P29/6P79



6P23  
6P25  
6P27  
6P29

small hands height



6P73  
6P75  
6P77  
6P79

center hands height




6P23  
6P25  
6P27  
6P29

center hands height




6P73  
6P75  
6P77  
6P79


## FS SERIES




FS00/FS03



FS01/FS04




FS10/FS13




FS11/FS14

NEW



FS20/FS23




FS21/FS24

NEW



FS00 FS03  
FS01 FS04

small hands height




FS00 FS03  
FS01 FS04

center hands height



FS10 FS13  
FS11 FS14  
FS20 FS23  
FS21 FS24

small hands height



FS10 FS13  
FS11 FS14  
FS20 FS23  
FS21 FS24

center hands height

## OS SERIES




OS10/OS1A




OS10 OS1A

small hands height



OS10 OS1A

center hands height




OS20/OS2A



OS20 OS2A

small hands height



OS20 OS2A

center hands height