

Bestfit Material Instant Guide

CLOCK

22L. ANGELUS 190-195

402	402	402	7436	203	7290	7498	7498	420	420	7149	421	7405
401/1	401/2	401/3	X21	X14	X15		X29	X3371	X22	MIS/541	420/16	X16
7405	7405	7496	7496	7487	7459	7480	7288	7288	7288	415	7418	
X18	X19	X26	X27		X20		X17	X23	X25	X28	X24	


EB No.
BF Pos.
No.

22L. ANGELUS 190-195 CALENDAR

2560	2577	2578	2566	2566/1	2543	2556	2577-2578	2557	2558	2543	2561	2562	A	B	2543
			X3421					250/966							
A	2577				2556	2577/2578	2566	2566/1	2588/1	B	C		2587	2588	
	X3411														


EB No.
BF Pos.
No.

16L. ANGELUS 240 — 8 DAY KEY WIND



16L. ANGELUS 240 — 8 DAY ALARM KEY WIND

For Alarm Parts See ANGELUS 240 STEM WIND ALARM



16L. ANGELUS 240 — 8 DAY ALARM — STEM WIND


			420	7149	250	7405	7290	7498
					250/15			
			260	7288	7298	7405	7405	7459
					450/15			X90
7418	424	410	407	424	7478			

EB No.
BF Pos.
No.


BESTFIT insures GENUINE FACTORY SWISS MATERIAL

CLOCK


16L. ANGELUS 240 — 8 DAY STEM WIND



16L. ANGELUS 240 CALENDAR



22L. ANGELUS 390-490 — 8 DAY ALARM — SIDE SHUT-OFF BUTTON KEY WIND



22L. ANGELUS 391 — 8 DAY ALARM — BACK SHUT-OFF BUTTON — KEY WIND

For All Other Parts Use ANGELUS 390

