




PARTS LIST

Cal. 4R15/16




Disassembling procedures Figs. : ① → ⑤⑧

Reassembling procedures Figs. : ⑤⑧ → ①


Lubricating: Types of oil

-  AO-3 (Moebius A)
-  SEIKO Watch Oil S-6
-  SEIKO Watch Oil S-4

Oil quantity

-  Liberal quantity
-  Normal quantity
-  Small quantity

[CALENDAR MECHANISM]



Only for Cal. 4R16


For parts ②, ⑦ and ⑭, refer to "REMARKS" on page 6.

PARTS LIST

Cal. 4R15/16

[BALANCE AND ESCAPEMENT]


[WINDING MECHANISM (1)]



PARTS LIST

Cal. 4R15/16

[WINDING MECHANISM (2), GEAR TRAIN MECHANISM AND SETTING MECHANISM]



* For parts 57, refer to
"REMARKS" on page 6.

