



Diese Uhr ist mit einer automatischen Nachtabschaltung, 3 wählbaren Melodien und einem Schlagabsteller ausgestattet.

Nachtabschaltung

In der oberen Position des Hebels ist die Nachtabschaltung in Betrieb. Der Schlag ist von abends 21.45 Uhr bis morgens 6.00 Uhr ausgeschaltet. Sollte der Schlag schon morgens 9.45 Uhr abstellen, ist die Uhr genau um 12 Stunden zu verstellen.

Melodienwahl

Mit diesem Hebel können 3 verschiedene Melodien eingestellt und der Schlag abgestellt werden. In der jeweiligen Position ist eine Rastung spürbar. Hebel nicht während dem Schlag betätigen!

This clock is equipped with Automatic Night Shut-Off and a Selector Lever for 3 Melodies and Melody Shut-Off.

Night Shut Off

Night Shut-Off is activated with lever at highest position.

Once activated, the clock will not chime between 21.45 and 6.00 hours. If the clock fails to chime at 09.45 hours, gently turn minute hand clockwise 12 hours.

Melody Selection

With this lever, you can decide which melody the clock should play. You will notice some slight friction in various positions. Do not attempt to move the lever when the clock is chiming!