

82S5

BALANCE BRIDGE	710-191
BALANCE WITH HAIRSPRING REGULATED	039-102
BARREL AND TRAIN WHEEL BRIDGE	701-F52
BARREL COMPLETE	001-870
CALENDAR CORRECTOR LEVER	-
CALENDAR CORRECTOR LEVER SPRING	-
CENTER SECONDS PINION	-
CENTER WHEEL & PINION	012-A11
CENTER WHEEL COCK	711-074
CLICK	060-390
CLICK SPRING	903-700
CLUTCH WHEEL	064-450
CROWN WHEEL	058-360
DATE DIAL	-
24HOUR WHEEL	-
24HOUR WHEEL	-
DATE DIAL DRIVING WHEEL	-
DATE INDICATOR MAINTAINING PLATE / HOUR WHEEL SPRING	176-109
DIAL WASHER	078-140
ESCAPE WHEEL AND PINION	032-106
FORTH WHEEL AND PINION	023-A12
HOUR WHEEL	075-487
INTERMEDIATE DATE WHEEL	-
JeweLED PALLET FORK AND STAFF	035-560
JUMPER	-
LOWER CAP JEWEL MOUNTED	094-250
MINUTE TRAIN COVER	079-890
MINUTE WHEEL AND PINION	072-520
MOVEMENT HOLDER (PLASTIC)	500-710
OSCILLATING WEIGHT	119-A17
PALLET BRIDGE	708-066
PINION FOR 24 HOUR WHEEL	-
PINION FOR 24 HOUR WHEEL SPRING	-
RATCHET SLIDING WHEEL	087-250
RATCHET SLIDING WHEEL SPRING	078-150
RATCHET WHEEL	059-560
REDUCTION WHEEL AND PINION	088-120
REVERSING WHEEL	141-190
SCREW FOR BALANCE BRIDGE	924-460
SCREW FOR BARREL AND TRAIN WHEEL BRIDGE (x3)	924-460
SCREW FOR CENTER WHEEL COCK 1(x2)	923-600
SCREW FOR CLICK	924-460

SCREW FOR CLICK SPRING	923-600
SCREW FOR DATE INDICATOR MAINTAINING PLATE (x2)	-
SCREW FOR HOUR WHEEL SPRING (x4)	923-630
SCREW FOR MINUTE TRAIN COVER (x2)	923-630
SCREW FOR OSCILLATING WEIGHT	925-490
SCREW FOR PALLET BRIDGE	923-600
SCREW FOR PINION FOR 24 HOUR WHEEL SPRING	-
SCREW FOR SETTING LEVER SPRING	923-640
SCREW FOR STUD	920-010
SCREW FOR YOKE	923-640
SECONDS PINION FRICTION SPRING	-
SETTING LEVER	067-860
SETTING LEVER SPRING	077-690
SETTING STEM	065-212
SETTING WHEEL	076-430
SPIRAL SPRING WITH JEWEL(x2)	098-090
THIRD WHEEL AND PINION	017-760
UPPER CAP JEWEL MOUNTED	094-260
YOKE	071-510
** LONGER SETTING STEM(24.0MM) **	065-A06