

## 6T33

BALANCE BRIDGE	710-207
BALANCE WITH HAIRSPRING REGULATED	039-690
BARREL AND TRAIN WHEEL BRIDGE	701-H17
BARREL COMPLETE	001-994
CAP JEWELLED SPRING	933-050
CENTER SECONDS PINION	025-920
CENTER WHEEL & PINION	012-207
CENTER WHEEL COCK	711-159
CLICK	060-490
CLICK SPRING	902-250
CLUTCH WHEEL	064-210
FRICTION SPRING FOR SWEEP SEC PINION	903-360
DIAL WASHER	078-040
ESCAPE WHEEL AND PINION	032-840
FORTH WHEEL AND PINION	023-700
HOUR WHEEL	075-378
HOUR WHEEL SPRING	176-A05
JEWELLED PALLET FORK AND STAFF	035-420
LOWER CAP JEWEL MOUNTED	094-240
MINUTE TRAIN COVER	079-250
MINUTE WHEEL AND PINION	072-340
PALLET BRIDGE	708-054
RATCHET WHEEL	059-440
SCREW FOR BALANCE BRIDGE	922-172
SCREW FOR BARREL AND TRAIN WHEEL BRIDGE (x3)	922-172
SCREW FOR CENTER WHEEL COCK (x2)	922-172
SCREW FOR CLICK	921-320
SCREW FOR HOUR WHEEL SPRING (x2)	929-550
SCREW FOR MINUTE TRAIN COVER	929-550
SCREW FOR PALLET BRIDGE	922-173
SCREW FOR SETTING LEVER SPRING (x2)	929-550
SCREW FOR STUD	927-020
SETTING LEVER	067-997
SETTING LEVER SPRING	077-390
SETTING STEM	065-117
SETTING WHEEL	076-270
SPIRAL SPRING WITH JEWEL(x2)	098-040
THIRD WHEEL AND PINION	017-520
UPPER CAP JEWEL MOUNTED	094-240
WINDING PINION	063-200
YOKE	071-122
YOKE SPRING	902-260

