

A*F SCREW REMOVING & FITTING TOOL

No 189.815

This tool is designed for removing and replacing screws in watch bracelets or watch cases.

Instructions for Use :

1. Place the tool in the upright position.
2. Raise the spring-loaded upper blade holder (1).
3. Position the bracelet against the centre support (3).
4. Lower the upper blade holder and turn until the blade sits in the screw slot.
5. Turn the lower blade holder (2) until the blade engages with the opposite screw on the bracelet.
6. Hold the lower blade holder to prevent turning and rotate the upper blade holder to unscrew the screw.
7. To replace screws reverse the procedure.

The plastic collars (4) around the blades are designed to assist in positioning and preventing damage to the screws. If necessary, the user can trim away the collars below the end of the blade.

The blades can be changed by unscrewing the fixing screws (5) on the side of the blade holders. To remove the bottom blade holder, the centre support must be pulled away from the main body.

The two replacement blades are stored in the back of the tool which can be opened by pressing the bottom of the back plate where marked «open here».

This compartment can be used for storing other parts if needed.

