


Furring caused by humidity (condensation) and dirt (dust particles) impair the function of the valves of the Poseidon LT-100.

Therefore we recommend that your compressor is provided with a maintenance unit in order to exclude damage to the equipment.

Should arise damage to the Poseidon LT-100 by neglect of this recommendation, we reject each guarantee for this.

Following maintenance unit can be furnished by us:



Maintenance unit consist of:

- compressed air filter
- high level filter with contamination indicator
- connection block
- attaching bracket
- semiautomatic drainage
- air filter element 5um
- air filter element 0.01 um
- 2 fast clutches
- hose for connection with compressor

User Manual- Poseidon LT-100