


Genuine OptiVisor® Parts

Visor To Headband Pivot Screw Assembly Instructions

- 1) Insert the pivot screw through the recessed square hole inside the headband.
- 2) Place the spring and fiber washer over the pivot screw as shown in the figure below.
- 3) Align the square hole of the bearing plate over the square pivot screw and thread on tension nut.
- 4) Tighten the tension nut to completely compress the spring washer then loosen to desired amount of tension.



Donegan Optical Company, Inc.

Rev. 08/15/05