

***** **CAL. 23XX MOV'T PART LIST** *****
 ORIGINAL PARTS, MADE IN JAPAN

| <u>PART NAME</u> | <u>2305</u> | <u>2315</u> | <u>2350</u> | <u>2353</u> |
|-----------------------------------|-------------|-------------|-------------|-------------|
| BATTERY | 280-390 | 280-390 | 280-390 | 280-390 |
| BATTERY CLAMP | 234-A81 | 234-A76 | 234-A82 | 234-A80 |
| BATTERY CONNECTOR SPRING | 231-105 | 231-105 | 231-105 | 231-105 |
| CORRECTOR INT. WHEEL | 087-420 | 087-420 | 087-420 | 087-420 |
| CORRECTOR LEVER | 116-360 | 116-125 | 116-360 | 116-125 |
| CORRECTOR WHEEL | 213-200 | 213-200 | 213-200 | 213-200 |
| CALENDAR PLATE | 714-063 | 714-061 | 714-063 | 714-061 |
| CENTER WHEEL | 028-600 | 028-600 | 028-600 | 028-600 |
| CENTER WHEEL COCK | 711-100 | 711-100 | 711-100 | 711-100 |
| CLUTCH WHEEL | 064-660 | 064-660 | 064-660 | 064-660 |
| CLUTCH WHEEL GUARD | 212-200 | 212-200 | 212-200 | 212-200 |
| COIL UNIT | 246-144 | 246-144 | 246-144 | 246-144 |
| DATE DIAL | 108-H6XX | 108-H1XX | 108-H7XX | 108-H5XX |
| DATE DIAL DRIVING WHEEL | 103-760 | 103-126 | 103-760 | 103-126 |
| DATE DIAL GUARD | 293-340 | 293-128 | 293-340 | 293-128 |
| DAY DIAL GIB | 178-140 | ----- | 178-140 | ----- |
| DAY DIAL | 308-A7XX | ----- | 308-A8XX | ----- |
| ELECTRONIC CIRCUIT UNIT | 279-G44 | 279-G44 | 279-G44 | 279-G44 |
| FIFTH WHEEL AND PINION | 084-190 | 084-190 | 084-190 | 084-190 |
| FOURTH WHEEL AND PINION | 023-154 | 023-154 | 023-154 | 023-154 |
| HOURLY WHEEL | 075-192 | 075-545 | 075-192 | 075-545 |
| JUMPER | 109-430 | 109-430 | 109-430 | 109-430 |
| MINUTE WHEEL AND PINION | 072-760 | 072-760 | 072-760 | 072-760 |
| ROTOR(Magnetized) | 285-202 | 285-202 | 285-202 | 285-202 |
| SCREW FOR COIL UNIT | 922-183 | 922-183 | 922-183 | 922-183 |
| SCREW FOR DATE DIAL GUARD | 929-390 | 922-194 | 929-390 | 922-194 |
| SCREW FOR ELECTRONIC CIRCUIT UNIT | 922-183 | 922-183 | 922-183 | 922-183 |
| SCREW FOR ELECTRONIC CIRCUIT UNIT | 922-154 | 922-154 | 922-154 | 922-154 |
| SCREW FOR TRAIN WHEEL BRIDGE(1) | 922-154 | 922-154 | 922-154 | 922-154 |
| SCREW FOR TRAIN WHEEL BRIDGE(1) | 934-440 | 934-440 | 934-440 | 934-440 |
| SETTING LEVER | 067-145 | 067-145 | 067-145 | 067-145 |
| SETTING STEM | 065-299 | 065-299 | 065-299 | 065-299 |
| SPACER | 212-319 | 212-319 | 212-319 | 212-319 |
| STATOR | 190-420 | 190-420 | 190-420 | 190-420 |
| THIRD WHEEL AND PINION | 017-103 | 017-103 | 017-103 | 017-103 |
| TRAIN WHEEL BRIDGE(-00A) | 701-933 | 701-933 | 701-933 | 701-933 |
| YOKE | 071-133 | 071-133 | 071-133 | 071-133 |