

## 1 Inspection and small maintenance for ACS 900

Area	Check or Clean	Replace if necessary	Remark
<b>Body</b> Clean body with a soft towel. Do not use aggressive cleaning liquid.	<input type="checkbox"/>		
<b>Doors / Side panels</b> Clean the doors and side panels with a soft towel. Do not use aggressive cleaning liquid.	<input type="checkbox"/>		
<b>Filter</b> Check the filter pads; they can be cleaned. If too dirty, replace them.	<input type="checkbox"/>	<input type="checkbox"/>	Filter pad 9650.01F.011
<b>Plate</b> Clean the plate with a soft towel. Do not use aggressive cleaning liquid.	<input type="checkbox"/>		
<b>Rubber discs</b> Clean the rubber discs with a soft towel. Do not use aggressive cleaning liquid. If too used, replace it.	<input type="checkbox"/>	<input type="checkbox"/>	4× Rubber disc (cover) 0322.350.014 1 × Rubber disc (basket holder) 0322.310.030
<b>Contacts of ultrasonic</b> Check and clean the ultrasonic contacts inside of the machine (in the whole where the ultrasonic tank is positioned) → Switch off the device and disconnect the power cable before doing this.	<input type="checkbox"/>		
<b>Ultrasonic tank</b> Check and clean the contacts on the underside of ultrasonic tank.	<input type="checkbox"/>		
<b>Mechanic</b> Check if play in the mechanic or large Vibration during spinning.		<input type="checkbox"/>	Contact service centre

## 2 Repair

Problem	Possible cause	Possible helps
No function	• ACS 900 not switched on	• Press the power switch
	• Power cord not plugged	• Insert cable
	• Fuse blown	• Replace fuse
	• Building no power	• Check power supply
Error message on display	• Mechanical defect	• Contact Service Centre
Ultrasonic is not running	• Ultrasound in the program not selected	• Activate in the program
	• Ultrasound cannot be selected in the program	• Contact Service Centre
Heating is not running	• Heating in the program not selected	• Activate in the program
	• Heating defective	• Contact Service Centre
Vibration, mechanical Noise, especially during spinning	• Play of mechanic	• Contact Service Centre
Plate is not centered	• Mechanical defect	• Contact Service Centre
Keyboard does not respond	• Keyboard defective	• Contact Service Centre
Cleaned parts are not clean	<ul style="list-style-type: none"> <li>• Liquids are too dirty</li> <li>• · Liquids are too old</li> <li>• · Liquids are too long in the ACS 900</li> </ul>	• Check liquids and replace if necessary
Baskets touch glasses	• Plate is not centered	• Contact Service Centre
ACS 900 makes noises	• Mechanical defect	• Contact Service Centre

- General remarks:**
- Do not use more than 0.55l of liquid for each bath.
  - The ultrasonic goblet is not waterproof.