

OPERATION INSTRUCTIONS FOR WEISHI TIMEGRAPHER PRINTER

Product name: Weishi Timegrapher Printer

Size: 205*125*92mm

Material: ABS

Weight: 740g

Output: 8.5V/3A

Input: 110-240V;50/60Hz

Power: 25.5W

Printing paper: 57.5 ± 0.5 mm

Printing method: Thermosensitive

Certificate: 3C

Version: English

Fit for: WEISHI2000/WEISHI3000/WEISHI5000/WEISHI6000III




The list of printer fittings:

- A、 Printer Machine
- B、 Printer Paper
- C、 Power Line
- D、 The Power Adapter
- E、 Data Transmission Line

1. Open The Printer Cover



2. Put The Paper Into The Printer




3. Printer Cover Reset




4. Connecting the power cable and adapter




5. Connect the power cable and data cable to the socket on the cack of the printer




6. Connect the other end of the data cable to the print option plug on the Weishi machine



7. Press the red "Pause" key after the Weishi machine shows data



8. Press the "Print" key of the Weishi machine



9. The result will be printed

