

※Please contact us when you order these parts. ※订购零件时请与我们联系

PARTS NAME 零件名称		PARTS CODE 零件编号	
		Type - M	Type - L
Train wheel bridge (A)	轮列夹板 (A)	0125 248	
Train wheel bridge (B)	轮列夹板 (B)	0125 331	
Auxiliary train wheel bridge	副夹板	0126 368	
Center wheel and pinion	中心轮	0221 203	※
Third wheel and pinion	3# 轮	0231 904	
Fourth wheel and pinion	4# 轮 (秒轮)	0241 178	※
Fifth wheel and pinion (A)	5# 轮 (A)	0701 904	
Fifth wheel and pinion (B)	5# 轮 (B)	0701 014	
Step rotor (A)	磁石轮 (A)	4146 890	
Step rotor (B)	磁石轮 (B)	4146 177	
Hour wheel	时轮	0271 407	※
Minute wheel and pinion	度数轮	0261 150	
Setting wheel	小铁车	0281 904	
Clutch wheel	离合轮	0282 890	
Setting lever	设置杆 (压制)	0383 368	
Yoke	离合杆 (横担)	0384 470	
Train wheel setting lever	规正弹弓	0391 368	
Rotor stator (A)	定子板 (A)	4239 357	
Rotor stator (B)	定子板 (B)	4239 357	
Circuit block	回路板	4004 339	
Coil block (A)	线圈 (A)	4002 904	
Coil block (B)	线圈 (B)	4002 021	
Coil block (C)	线圈 (C)	4002 021	
Battery connection(-)	负极片 (-)	4270 358	
Intermediate date driving wheel	日送中间轮	0817 368	
Date driving wheel	日送轮	0802 368	
Intermediate chronograph second wheel	秒计中间轮	0885 002	
Chronograph second wheel	秒计轮	0888 009	※
Intermediate chronograph minute wheel and pinion (A)	分计中间轮 (A)	0886 001	
Intermediate chronograph minute wheel and pinion (B)	分计中间轮 (B)	0886 003	
Chronograph minute wheel	分计轮	0902 008	※
Intermediate wheel for date corrector (A)	日历修正中间轮 (A)	0962 890	
Intermediate wheel for date corrector (B)	日历修正中间轮 (B)	0962 891	
Intermediate wheel for date corrector (C)	日历修正中间轮 (C)	0962 891	
Intermediate wheel for date corrector (D)	日历修正中间轮 (D)	0737 891	
Date corrector wheel	日历修正轮	0806 368	
Intermediate wheel for date corrector holder	日历修正中间轮压片	0836 369	
Date dial guard	日历压片	0808 368	
Date jumper	日历定位弹弓	0810 368	
Switch spring	按制弹弓	4250 104	※
Switch spring screw	按制弹弓螺丝	0012 079	
Train wheel bridge (B) screw	轮列夹板 (B) 螺丝	0012 079	
Auxiliary train wheel bridge screw	副夹板螺丝	0012 079	
Winding Stem (TYPE A)	巴芯	0351 177	
Winding Stem (TYPE B)	巴芯	0351 122	