

PARTS NAME 零件名称		PARTS CODE 零件编号
		Type - M
Barrel and train wheel bridge with hole jewel frame	轮列夹板	0114 183
Lower plate for barrel and train wheel bridge	发条鼓下夹板	0436 166
Center wheel bridge	中心轮夹板	0122 164
Pallet bridge	擒纵叉(马仔)夹板	0161 300
Balance cock	摆夹板组件(不带油丝)	0171 354
Balance complete with stud	油丝连夹板含外桩	0310 186
Automatic train bridge	自动锤夹板	0191 183
Barrel complete with mainspring	条盒轮(发条鼓)	0201 287
Center wheel and pinion	中心轮	0224 448
Cannon pinion	分轮(十反)	0225 341
Third wheel and pinion	3# 轮	0231 070
Fourth wheel and pinion	4# 轮(秒轮)	0144 245
Escape wheel and pinion	擒纵轮(莲花轮)	0251 383
Minute wheel and pinion	度数轮	0261 190
Hour wheel	时轮	0273 245
Clutch wheel	离合轮	0282 183
Winding pinion	企轮	0283 020
Ratchet sliding wheel spring	游动座弹弓	0363 184
Ratchet wheel	大钢轮	0285 051
Pallet fork	擒纵叉(马仔)	0301 383
Click	止逆爪(上鍊弹弓)	0381 004
Setting lever	设置杆(压制)	0383 185
Yoke	离合杆(横担)	0384 183
Yoke spring	离合杆簧(横担压片)	0388 177
Balance stop lever	止秒杆	0601 183
First reduction wheel	自动轮	0511 010
Second reduction wheel and pinion	逆轮	0514 183
Pawl lever	自动叉	0831 183
Reduction wheel holder	自动轮固定片	0836 002
Day-date corrector setting transmission wheel A	日历星期修正传动轮 A	0962 183
Day-date corrector setting transmission wheel B	日历星期修正传动轮 B	0962 190
Auxiliary main plate	第二(副)地板	0102 193
Auxiliary train wheel bridge	第二(副)轮列夹板	0126 196
Barrel arbor pinion	上鍊小轮	0538 001
Planetary reduction wheel	游星过轮	1026 002
Sun wheel	太阳轮	1009 003
Sun and planet unit	太阳及星轮套件	1001 025
Second sun wheel	第二太阳轮	1009 004
Intermediate power reserve wheel	能量储存中间轮	0817 047
Intermediate center power reserve wheel	中心能量储存中间轮	0817 190
Center power reserve wheel	中心能量储存轮	1019 190
Date driving wheel	日送轮	0802 036
Date star	日历轮	0970 102
Date jumper	日历定位弹弓	0810 164
Day-date corrector setting unit	日历星期修正套件	1001 128
Date corrector setting wheel	日历修正轮	0737 021
Dial washer	表面垫圈	0491 190
Dial spacer	中心面圈	0439 190

PARTS NAME 零件名称		PARTS CODE 零件编号
		Type - M
Dial holding spacer	表盘垫圈	4408 245
Ratchet wheel screw	大钢轮螺丝	0012 919
Barrel and train wheel bridge screw	轮列夹板(大夹板)螺丝	0012 100
Balance bridge screw	油丝夹板螺丝	0012 100
Lower plate for barrel and train wheel bridge screw	发条鼓下夹板螺丝	0012 354
Center wheel bridge screw	中心轮夹板螺丝	0012 354
Pallet bridge screw	擒縱叉(马仔)夹板螺丝	0012 354
Automatic train bridge screw	自动锤夹板螺丝	0012 354
Yoke spring screw	横担压片螺丝	0012 168
Auxiliary main plate screw	第二(副)地板螺丝	0012 201
Auxiliary train wheel bridge screw	第二(副)轮列夹板螺丝	0012 201
Winding Stem	巴芯	0351 200