

PARTS NAME 零件名称		PARTS CODE 零件编号
		Type - M
Barrel and train wheel bridge with hole jewel frame	轮列夹板	0114 183
Lower plate for barrel and train wheel bridge	发条鼓下夹板	0436 166
Center wheel bridge	中心轮夹板	0122 302
Pallet bridge	擒縱叉(马仔)夹板	0161 300
Balance cock	摆夹板组件(不带油丝)	0171 353
Balance complete with stud	油丝连夹板含外桩	0310 184
Automatic train bridge	自动锤夹板	0191 183
Barrel complete with mainspring	条盒轮(发条鼓)	0201 083
Center wheel and pinion	中心轮	0221 185
Cannon pinion	分轮(十反)	0225 426
Third wheel and pinion	3# 轮	0231 070
Fourth wheel and pinion	4# 轮(秒轮)	0144 185
Escape wheel and pinion	擒纵轮(莲花轮)	0251 383
Minute wheel and pinion	度数轮	0261 190
Hour wheel	时轮	0273 185
Clutch wheel	离合轮	0282 183
Winding pinion	企轮	0283 020
Ratchet sliding wheel spring	游动座弹弓	0363 184
Ratchet wheel	大钢轮	0285 051
Pallet fork	擒縱叉(马仔)	0301 383
Click	止逆爪(上鍊弹弓)	0381 004
Setting lever	设置杆(压制)	0383 186
Yoke	离合杆(横担)	0384 184
Yoke spring	离合杆簧(横担压片)	0388 177
Balance stop lever	止秒杆	0601 183
First reduction wheel	自动轮	0511 010
Second reduction wheel and pinion	逆轮	0514 183
Pawl lever	自动叉	0831 183
Reduction wheel holder	自动轮固定片	0836 002
Intermediate 24hour driving wheel and pinion	24小时中间轮	0817 300
24hour wheel	24小时轮	0157 184
Hour wheel guard	时轮定位片	0376 184
Dial holding spacer	表盘垫圈	4408 172
Ratchet wheel screw	大钢轮螺丝	0012 919
Barrel and train wheel bridge screw	轮列夹板(大夹板)螺丝	0012 100
Balance bridge screw	油丝夹板螺丝	0012 100
Lower plate for barrel and train wheel bridge screw	发条鼓下夹板螺丝	0012 354
Center wheel bridge screw	中心轮夹板螺丝	0012 354
Pallet bridge screw	擒縱叉(马仔)夹板螺丝	0012 354
Automatic train bridge screw	自动锤夹板螺丝	0012 354
Hour wheel guard screw	时轮定位片螺丝	0012 354
Yoke spring screw	横担压片螺丝	0012 168
Winding Stem	巴芯	0351 200