

PARTS NAME 零件名称		PARTS CODE 零件编号
		Type - M
Train wheel bridge	轮列夹板	0125 297
Center wheel and pinion	中心轮	0221 055
Third wheel and pinion	3# 轮	0231 066
Fourth wheel and pinion	4# 轮(秒轮)	0144 088
Fifth wheel and pinion	5# 轮	0701 170
Step rotor	磁石轮	4146 126
Hour wheel	时轮	0273 021
Minute wheel and pinion	度数轮	0261 291
Setting wheel	小铁车	0281 041
Clutch wheel	离合轮	0282 089
Train wheel setting lever	规正弹弓	0391 041
Rotor stator	定子板	4239 062
Circuit block with coil block	回路板连线圈	4004 303
Battery connection(+)	正极片(+)	4268 054
Battery connection(-)	负极片(-)	4270 385
Insulator	绝缘片	4216 088
Date corrector wheel	日历修正轮	0806 142
Date driving wheel	日送轮	0802 030
Date dial guard	日历压片	0808 044
Date jumper	日历定位弹弓	0810 890
Reset pin	止秒柱	0033 219
Pin for setting wheel	小铁车柱	0033 220
Screw for Battery connection(+)	正极片(+)螺丝	0016 121
Winding Stem (TYPE A)	巴芯	0351 332
Winding Stem (TYPE B)	巴芯	0351 001