

SK **Minecol**

STERNKREUZ

Adhesive for mineral glasses

Order-No. 224

Directions for use

1. STERNKREUZ-Minecol is a one-component adhesive which hardens by contact with UV rays.
2. The adhesive comes in a handy syringe with which it can be metet out easily. The fine hypodermic needle can be supplied seperately (order No. 225). An especially fine and short needle is additionally available under order No. 226.
3. The watch case with the glued-in glass should be left under a lamp with intense UV radiation (e. g. Osram-Ultra-Vitalux) at a distance of about 25 cm for approx. 2 - 3 minutes - depending on the adhesive gap. The case resp. the glass is then left to cool down by which time the adhesive will be hardened. Please protect your eyes against direct UV-rays.
4. After each time the syringe is used, the inner part must be retracted slightly so that no adhesive remains in the needle. To avoid the adhesive hardening before use please protect the syringe from being exposed to direct sunlight by putting it back into lightproof case and keeping it in a cool place.
5. The adhesive STERNKREUZ-Minecol can be removed from the watch case by scalding.

6. Minecol should not come into contact with the eyes and be kept away from food and beverages.

STERNKREUZ help you with all your problems concerning watch glasses