

Elmasolvex® RM - Automatic

Multiple-chamber technology for solvent and aqueous cleaning TÜV-certified Ex-protection



Can proven technology be improved?

- TÜV-certified Ex-protection
- now with 4 cleaning chambers and one drying chamber (fine filter warm air technology)
- completely automatic or alternatively with individually configurable parameters
- service-friendly and easy-to-care for design
- maximum personnel safety due to connection of the machine to controlled exhaust air routing
- basket frame for five baskets, optional holder for circuit boards
- wide range of practical accessories; see accessories catalogue

Process:

Rotation and oscillation process

Solvent cleaning:

flashpoint ≥ 12 °C; e.g. WF pro, 3 x Suprol pro, drying

Semi-aqueous combination process:

e.g. elma 1:9, demineralised water, 2 x elma suprol pro, drying
or elma 1:9, demineralised water, 2 x IPA, drying

Processes and media



Oscillation



Rotation



Solvent



Aqueous



64 mm
baskets

Elmasolvex® RM with wide range of accessories



Filling and inserting media containers



Inserting basket with watch parts



Connection to controlled exhaust air routing



Starting program

