



# WATER LEVEL GLASS LSE-3/C & LSE-6

HOW TO CHANGE?

1. REMOVE THE PLEXI PROTECTION FROM THE GLASS BY PULLING IT OUT



## 2. CLOSE-VERTICALLY THE YELLOW VALVES OF THE UPPER AND LOWER LEVEL GLASS





### 3. UNSCREW THE SCREWS OF THE WATER LEVEL GLASS

- By using spanner number 21, the upper nut clockwise and the bottom nut anti clockwise. Once the screw is open try to take out the glass gently. It might be difficult, in this case you break the glass by punching it in the middle of the glass.



## 4. MAKE SURE TO TAKE THE BROKEN PIECES FROM INSIDE BOTH ELBOWS

- The best way to do, is by using the tweezers to remove the pieces.



## 5. TAKE THE NEW GLASS



## 6. MAKE SURE TO PUT FIRST IN THE BOTTOM PIECE AND THEN FIT THE UPPER PIECE TOGETHER.

- You have to measure approx. 1 cm, the glass goes deep in the elbows, both upper and lower.





## 7. START TO CLOSE GENTLY THE BOTTOM SCREW CLOCKWISE AND THE UPPER SCREW ANTI CLOCKWISE

- When you tight the both nuts, do it gently. Lightly on the bottom, lightly on the upper.





## 8. ONCE YOU FEEL IT IS TIGHT ENOUGH, PUT BACK THE PLEXI PROTECTION

- Open the yellow valves. Than you can try out the machine.

