



SINCE 1975

INSTRUCTIONS:

Take the Precision Wax Tool out of the carton and familiarize yourself with the proper operation of the illuminated on/off switch and temperature control knob. Before plugging in unit, make certain dial is set to 0 and switch is in the off position. Proper placement of tip into handpiece is crucial. Tip is easily placed into handpiece by aligning tip prongs with the etched line across the front of the handpiece. Place tip into handpiece. Plug unit into outlet and turn on switch. Make certain that the tip does not touch the power cord or the handpiece cord of the unit. Proper handling of the handpiece is highly recommended because tip may be hot even when dial is set to 0. If tip does not heat up, check the contacts, loosen the tightening screw on the handpiece, realign tip to ensure proper contact and re-tighten screw.

Always turn off unit when not in use and place handpiece and tip into holder.

Reminder: Tip can be extremely hot- BE VERY CAUTIOUS!

Thank you very much for your purchase