English



Polishing Machine Nr. 7224



User Manual

Bergeon & Cie SA

Av. Du Technicum 11 2400 Le Locle Suisse Tel. +41 32 933 60 00 Fax +41 32 933 60 01 www.bergeon.ch E-Mail: info@bergeon.ch

1. Contents		Page	2
2. Introduction	on	Page	3
3. Safety inst	tructions	Page	4
4. Technical data			5 - 7
4.1	Technical data list		
4.2	Scale of speed level, continuous ac	ljustmei	nt
4.3	Overview of device		
4.4	Scope of delivery		
4.5	Special accessories		
5. Before put	ting into service	Page	8
6. Operation	elow. Perform the necessary in Interience this is the only way that sale, effective has	Page	9 -12
6.1	Lighting		
6.2	Suction		
6.3	Polishing motor		
6.4	Filter system 6.4.1 Structure of filter system 6.4.2 Cleaning the filter		
7. Disposal		Page	13
8. CE - Confirmation			14

2. Introduction

Our polishing machine 7224 is a new development with certain technical refinements that set it apart from other devices in many respects. The device stands out thanks to its modern design and from an ergonomic point of view.

This device was developed as a logical continuation of the following concept: EFFICIENCY THANKS TO SOLID, COMPACT EQUIPMENT DESIGN.

Give your workpieces an individual finish by means of polishing, brushing and matting in the glare-free, ergonomically designed polishing workspace. A high level of user-friendliness is achieved by the hinged hood and removable Plexiglas® cover over the working area. The redesigned air flow guarantees excellent suction output.

With the polishing machine 7224, all polishing jobs are possible under professional conditions and, as usual, we guarantee performance, reliability and a long service life.

We congratulate you on your purchase of this high-performance device.

We wish you many years of satisfaction with this unit and would like to ask for your help in this respect: before putting the device into service, please read through this Operating Manual carefully. Please familiarise yourself and the personnel who will be working with the unit with the polishing machine 7224 and comply with the safety instructions provided below. Perform the necessary maintenance and cleaning jobs at regular intervals, as this is the only way that safe, effective handling can be guaranteed.

Please keep the Operating Manual close to the device and accessible at all times. We would also ask you to kindly retain the original packaging.

Please read and comply with <u>all</u> safety instructions ! They should simplify handling the device and help to prevent any misunderstandings, as well as material or immaterial damage.