



<b>Calibre No. 5619A</b> <small>Basic Calibre 5606A <sup>23J</sup>/<sub>25J</sub> Catalog No. 56-06-1</small>	<b>Jewels 23j</b>	<b>Style Name</b>
--	-------------------	-------------------



Cal. 5619A



### Characteristics

- Casing diameter : 25.60  $\phi$ mm
- Maximum height : 4.25 mm
- Vibrations per hour : 21,600
- Automatic and auxiliary hand winding with sweep second and sub-hour hand
- Calendar (date)
- Instant date and sub-hour hand setting (rotating crown)
- Second-setting device
- Micro-adjustor
- "Diashock" Shock Resistant Device
- "Diafix" Oil Lubrication Device



271 569



376 569



509 555



981 569



990 569

Calibre No. <b>5619A</b>		Jewels <b>23j</b>	Style Name	
⇒ Basic Calibre <b>5606A</b> <sup>23J</sup> / <sub>25J</sub> Catalog No. 56-06-1				
PART NO.	LIST OF MATERIALS	PART NO.	LIST OF MATERIALS	
112 560	Barrel & train-wheel bridge (with crown wheel)	☆ 884 560	Holding ring for dial	
161 560	Pallet cock	<b>981 569</b>	<b>Day-date corrector wheel rocker</b>	
171 560	Balance cock (with micro-adjustor wheel)	986 560	Day-date corrector wheel rocking lever	
189 560	Transmission wheel bridge	987 560	Day-date corrector wheel rocking lever spring	
205 560	Complete barrel with arbor			
213 560	Barrel arbor	989 560	Intermediate wheel for sub-hour hand correction	
220 560	Large driving wheel & pinions	<b>990 569</b>	<b>Date driving wheel holder</b>	
225 560	Cannon pinion	022 150	Stud screw	
231 560	Third wheel & pinion	022 252	Transmission wheel bridge screw	
241 560	Sweep second wheel & pinion	022 257	Screw for day-date corrector wheel rocking lever spring	
251 560	Escape wheel & pinion			
261 560	Minute wheel	022 373	Pallet cock screw	
<b>271 569</b>	<b>Hour wheel</b> <b>(with sub-hour hand wheel)</b>	022 454	Screw for reverser idler bolt	
282 560	Clutch wheel	022 458	Screw for oscillating weight	
283 560	Winding pinion	022 467	Ratchet wheel screw	
285 560	Ratchet wheel	022 482	Intermediate wheel screw for sub-hour hand correction	
301 560	Jewelled pallet fork & staff			
310 560	Balance complete with stud	022 484	Bridge screw	
315 560	Balance staff	022 486	Minute wheel bridge screw	
331 560	Roller with jewel	022 662	Setting lever spring screw	
341 560	Regulator	022 667	Second-setting lever screw	
345 612	Stud holder	022 673	Screw for date driving wheel	
354 560	Winding stem	022 674	Screw for day-date corrector wheel rocking lever	
361 560	Second-setting lever spring			
367 560	Minute wheel spring	022 753	Date dial guard screw	
<b>376 569</b>	<b>Hour wheel guard</b>	022 753	Hour wheel guard screw	
381 560	Click	022 761	Dial screw	
☆ 383 560	Setting lever	011 147	Upper hole jewel for large driving wheel & pinions	
☆ 383 561				
☆ 383 562				
384 560	Yoke (Clutch lever)	011 147	Lower hole jewel for large driving wheel & pinions	
385 560	Yoke spring (Clutch lever spring)			
387 560	Minute wheel bridge	011 323	Lower hole jewel for 3rd wheel	
388 560	Setting lever spring	011 423	Lower hole jewel for escape wheel	
390 560	Setting lever axle	011 503	Upper hole jewel for pallet	
391 560	Second-setting lever	011 503	Lower hole jewel for pallet	
401 560	Mainspring with slipping attachment	011 147	Lower hole jewel for 1st reverser idler	
014 363	Diashock upper frame	011 151	Upper hole jewel for differential wheel	
014 384	Diashock lower frame	011 133	Lower hole jewel for differential wheel	
014 365	Diashock hole jewel with frame	011 159	Upper hole jewel for transmission wheel	
011 210	Diashock cap jewel	011 159	Lower hole jewel for transmission wheel	
014 317	Diashock spring	023 179	Tube for minute wheel bridge screw	
015 421	Diafix upper hole jewel with frame for 3rd wheel	023 180	Tube for bridge screw (Cylinder type)	
015 411	Diafix upper hole jewel with frame for escape wheel	023 184	Tube for bridge screw (Recessed type)	
011 206	Diafix cap jewel			
015 113	Diafix spring			
<b>509 555</b>	<b>Oscillating weight with ball-bearing</b>			
505 560	Transmission wheel			
531 560	Differential wheel			
848 560	First reverser idler			
851 560	Second reverser idler			
854 560	Reverser idler bolt			
☆ 801 560	Date dial			
802 560	Date driving wheel			
803 560	Setting wheel lever complete			
808 560	Date dial guard			
810 560	Date jumper			
812 560	Setting wheel lever spring			
817 610	Intermediate date wheel			

☆⇒ Please see remarks on the next page.

Items in light letters are not shown in photos; those parts are interchangeable with the basic calibre

(Cal. No. **5606A** <sup>23J</sup>/<sub>25J</sub> Catalog No. 56-06-1 Green page).

Calibre No.

5619A

Jewels

23j

Style Name

⇒ Basic Calibre 5606A <sup>23J</sup>/<sub>25J</sub> Catalog No. 56-06-1

Remarks :

Setting lever

There are three types of setting levers, used according to the dial diameter. Select the suitable setting lever by referring to the shapes indicated in fig. 1.

When a setting lever unsuitable for the dial diameter is used, the winding stem cannot be pulled out or the movement cannot be assembled in the case. Pay attention to this point (refer to fig. 2).

[fig. 1]



☆ 383 560



☆ 383 561



☆ 383 562

When the dial is round, the number of the setting lever differs (listed below) according to the dial diameter.

- (Dial diameter) 25.5 ~ 26.5 φ mm ..... ☆ 383 561
- ( " ) 27.5 ~ 28.5 φ mm ..... ☆ 383 560
- ( " ) 29.5 ~ 30.5 φ mm ..... ☆ 383 562

[fig. 2]

When the setting lever is too small

X



Setting lever

When the setting lever is too large

X



Setting lever

Correct

O



Setting lever

Setting lever is hidden under the dial and the winding stem cannot be pulled out.

Blocked by the setting lever, the movement cannot be assembled in the case.

End of the setting lever is located between the dial and the case.

Date dial

☆ 801 560 ..... Used when both the crown and the date frame are located at 3 o'clock.

If the date dial is required in any other type, specify ① Cal. No. ② the crown position ③ the date frame position and ④ the dial No.

Holding ring for dial — Measure the total thickness and the outside diameter —

☆ 884 560 ..... 0.53 mm total thickness and 27.0 φ mm outside diameter.

If the holding ring for dial is required in any other type, specify ① Cal. No. and ② the dial No.