

VENTURA 2 EXTRACTOR / POLISHER

YOUR VENTURA 2 POLISHING EXTRACTOR UNIT WILL GIVE MANY YEARS OF SERVICE. TO MAINTAIN THE MACHINE IN GOOD WORKING CONDITION THE FOLLOWING PROCEDURES SHOULD BE CARRIED OUT.

1. CLEAN ONLY WITH A CLOTH AND DETERGENT-SOLVENTS OR ABRASIVES WILL DAMAGE THE POWDER COATED SURFACE.
2. USE POLISHING MOPS UP TO A MAXIMUM OF 150MM X 25MM.
3. DO NOT FORCE ITEMS ONTO THE WHEEL AND CAUSE THE POLISHING MOTOR TO SLOW DOWN. WE FIT 0.5HP MOTORS THAT ARE POWERFUL ENOUGH FOR ALL NORMAL POLISHING OPERATIONS.
WHEN POLISHING, DO NOT WEAR LONG CHAINS OR LOOSE CLOTHING, DO NOT STOP THE POLISHING MOTOR BY HAND.
4. EVERY 20 WORKING HOURS, OR MORE FREQUENTLY IF LARGE AMOUNTS OF DUST IS PRODUCED, REMOVE THE FILTER AND SHAKE EXCESS DUST AWAY.
TO CHANGE THE FILTER IF THE SUCTION IS REDUCED. UNSCREW THE 2 SCREWS ON EACH SIDE AND UNSCREW THE LARGE BAND CLAMP HOLDING THE FILTER BAG. CAREFULLY REMOVE THE BAG AND SHAKE THE RESIDUE INTO A SUITABLE CONTAINER. REPLACE THE BAG AND REFIT THE CLAMP AND SIDE PANELS.
THE BAGS MAY BE WASHED BUT SHOULD BE REPLACED EVERY 800 HOURS OF USE.
5. CHECK POWER CABLE OCCASIONALLY FOR ANY DETERIORATION, CHAFFING OR CRACKING.

THE VENTURA 2 © POLISHING MACHINE IS DESIGNED TO BE CONNECTED TO A 220-240 VOLT AC SUPPLY. A 5 AMP FUSE SHOULD BE FITTED TO THE PLUG TOP IN GREAT BRITAIN.